

Preliminary



User's Manual (SMDK-C100 Rev0.0)

S5PC100X

RISC Microprocessor

October 15, 2008

REV 0.0

Important Notice

The information in this publication has been carefully checked and is believed to be entirely accurate at the time of publication. Samsung assumes no responsibility, however, for possible errors or omissions, or for any consequences resulting from the use of the information contained herein.

Samsung reserves the right to make changes in its products or product specifications with the intent to improve function or design at any time and without notice and is not required to update this documentation to reflect such changes.

This publication does not convey to a purchaser of semiconductor devices described herein any license under the patent rights of Samsung or others.

Samsung makes no warranty, representation, or guarantee regarding the suitability of its products for any particular purpose, nor does Samsung assume any liability arising out of the application or use of any product or circuit and specifically disclaims any and all liability, including without limitation any consequential or incidental damages.

S5PC100X RISC Microprocessor SMDK_C100 User's manual, Revision 1.00

Copyright © 2008 Samsung Electronics Co.,Ltd.

All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electric or mechanical, by photocopying, recording, or otherwise, without the prior written consent of Samsung Electronics Co.,Ltd.

Samsung Electronics Co., Ltd.
San #24 Nongseo-Dong, Giheung-Gu
Yongin-City Gyeonggi-Do, Korea
446-711

Home Page: <http://www.samsungsemi.com/>

E-Mail: mobilesol.cs@samsung.com

Printed in the Republic of Korea

"Typical" parameters can and do vary in different applications. All operating parameters, including "Typicals" must be validated for each customer application by the customer's technical experts.

Samsung products are not designed, intended, or authorized for use as components in systems intended for surgical implant into the body, for other applications intended to support or sustain life, or for any other application in which the failure of the Samsung product could create a situation where personal injury or death may occur.

Should the Buyer purchase or use a Samsung product for any such unintended or unauthorized application, the Buyer shall indemnify and hold Samsung and its officers, employees, subsidiaries, affiliates, and distributors harmless against all claims, costs, damages, expenses, and reasonable attorney fees arising out of, either directly or indirectly, any claim of personal injury or death that may be associated with such unintended or unauthorized use, even if such claim alleges that Samsung was negligent regarding the design or manufacture of said product

Revision History

Rev. No	Description of Change	Refer to	Author(s)	Effective Date (MM/DD/YY)
0.00	- Initial Release (SMDK_C100 Rev0.00)		J.K. RYOO	October, 15,2008



Table of Contents

1	INTRODUCTION	7
1.1	SYSTEM OVERVIEW	7
1.2	SMDK C100 FEATURES	9
2	SMDK C100 REAL VIEW	10
2.1	SMDK C100 CPU BOARD REAL VIEW	10
2.2	SMDK C100 BASE BOARD REAL VIEW	11
2.3	SMDK C100 LCD BOARD REAL VIEW	14
3	CIRCUIT DESCRIPTION	15
3.1	POWER DISTRIBUTION TREE	15
3.2	FUNCTIONAL BLOCK DIAGRAM	17
4	SMDK C100 SYSTEM CONFIGURATIONS	18
4.1	PLL CLOCK SOURCE SELECTION	19
4.2	BOOT MODE SELECTION	19
4.2.1	Switch Configuration	19
4.3	CONFIGURATION SWITCH DESCRIPTION IN CPU BOARD	20
4.3.1	CFGB3: FOR USING Controllable Regulator (ARM/INT)	20
4.3.2	CFG1: SELECTION FOR MAIN POWER SUPPLY	21
4.3.3	CFGB1: HDMI I2C Channel	21
4.3.4	CFGB2: SELECTION BETWEEN CAM-A AND MMC1/2	21
4.4	CONFIGURATION SWITCH DESCRIPTION IN BASE BOARD	22
4.4.1	CFGB1: SROM BANK0 CHIP SELECTOR	22
4.4.2	CFGB2: SROM BANK1 CHIP SELECTOR	22
4.4.3	CFGB3: SROM BANK2 CHIP SELECTOR	22
4.4.4	CFGB4: SROM BANK3 CHIP SELECTOR	23
4.4.5	CFGB5: SROM BANK4 CHIP SELECTOR	23
4.4.6	CFG8: CF CARD TRANSFER MODE SELECTOR	23
4.4.7	CFG1: COM PORT CONTROL	24
4.4.8	CFG2: KEYPAD/ CAM B CONTROL	24
4.4.9	CFG3: KEYPAD/ CAN2.0 CONTROL	24
4.4.10	CFG4: S/PDIF SELECTOR	24
4.4.11	CFG5: WM8580 MASTER CLOCK SELECTOR	25
4.4.12	CFG6: AUDIO CONNECTOR	25
4.4.13	CFG7: AUDIO SELECTOR	25
4.5	JUMPER SETTING CONFIGURATION	26
5	Appendix : CONNECTORS	28
5.1	CPU BOARD	28
5.1.1	JTAG	28
5.1.2	USB	28
5.1.3	SPI	29
5.1.4	MIPI HSI	29
5.1.5	SD host (Ver2.0) /MMC interface	30
5.1.6	EXTERNAL ONE-NAND connector	31
5.1.7	Camera Interface –A Connector	32
5.1.8	PMIC connector	33
5.1.9	HDMI Connector	33
5.1.10	MIPI-CSI	34
5.1.11	MIPI-DSI	35
5.1.12	TFT LCD I/F CONNECTOR	35
5.2	BASE BOARD	37
5.2.1	Component, Composite & S-VIDEO Connector	37
5.2.2	LINE IN, MIC IN & SPEAKER OUT Connector	37
5.2.3	ETHERNET CONNECTOR	38
5.2.4	UART interface	38



5.2.5	xD Picture Card Connector.....	39
5.2.6	CF Card Slot	40
5.2.7	PWM connector	40
5.2.8	Camera Interface- B.....	40
5.2.9	CAN 2.0 Interface.....	41
5.2.10	S/PDIF 5.1 Channel Audio Interface.....	42
5.3	EXTERNAL CONNECTOR INTERFACE	43
5.3.1	ROM BUS Interface	43
5.3.2	HOST/MODEM INTERFACE.....	44
5.3.3	EXTERNAL KEYPAD CONNECTOR.....	45
5.3.4	MODULE1: FOR GPS DAUGHTER BOARD	46
5.3.5	MODULE2: FOR MOBILE TV, HD RADIO DAUGHTER BOARD.....	47
5.3.6	MODULE3: FOR BLUETOOTH DAUGHTER BOARD.....	47
5.3.7	MODULE4: FOR AUDIO DAUGHTER BOARD.....	48
5.3.8	MODULE5: FOR LCD BOARD (with Touch Screen).....	49
6	SMDK SCHEMATIC REVISION HISTORY	51
7	SMDK SCHEMATIC	52



Figure List

Figure 1 S5PC100X Functional Block Diagram.....	8
Figure 2 S5PC100X CPU BOARD TOP VIEW	10
Figure 3 S5PC100X CPU BOARD BOTTOM VIEW.....	11
Figure 5 S5PC100X BASE BOARD BOTTOM VIEW.....	13
Figure 6 S5PC100X LCD BOARD TOP VIEW	14
Figure 7 S5PC100X LCD BOARD BOTTOM VIEW	14
Figure 8 S5PC100X BASE BOARD POWER DISTRIBUTION TREE	15
Figure 9 S5PC100X CPU BOARD POWER DISTRIBUTION TREE	16
Figure 10 S5PC100X SMDK FUNCTIONAL BLOCK DIAGRAM.....	17
Figure 11 JTAG Connector	28
Figure 12 One USB ports & OTG port.....	29
Figure 13 SPI port	29
Figure 14 MIPI-HSI port	30
Figure 15 SD/MMC port	30
Figure 16 MMC port	31
Figure 17 One NAND memory port.....	32
Figure 18 Camera Interface -A port	32
Figure 19 PMIC Connector.....	33
Figure 24 Component, Composite & S-VIDEO Connector.....	37
Figure 26 100Base-T Ethernet Socket	38
Figure 27 UART Sockets	39



1 INTRODUCTION

1.1 SYSTEM OVERVIEW

SMDK_C100 (_C100 Development Kit) is a platform for code development of SAMSUNG's S5PC100X 16/32-bit RISC microcontroller (ARM-CORTEX A8). S5PC100X is used in hand-held devices and general applications.

The S5PC100X is a 32-bit RISC cost-effective, low power, high performance microprocessor solution for mobile phones and general applications, and integrates an ARM Cortex-A8 which implements the ARM architecture V7-A with numerous peripherals to support.

To provide optimized H/W performance for the 3G & 3.5G communication services, S5PC100X adopts 64-bit internal bus architecture and includes many powerful hardware accelerators for tasks such as motion video processing, display control and scaling. Integrated Multi Format Codec (MFC) supports encoding and decoding of MPEG-1/2/4, H.263, H.264 and decoding of VC1, Divx. This Hardware accelerators support real-time video conferencing and Analog TV out, HDMI for NTSC and PAL mode

The S5PC100X has an optimized interface to external memory capable of sustaining the demanding memory bandwidths required in high-end communication services. The memory system has Flash/ROM external memory ports for parallel access and DRAM port for high bandwidth. DRAM port can be configured to support DDR2,mobile-DDR(LPDDR1) or LPDDR2.

Flash/ROM Port supports NAND Flash, NOR-Flash, OneNAND and ROM type external memory.

To reduce total system cost and enhance overall functionality, S5PC100X includes many hardware peripherals such as TFT 24-bit true color LCD controller, Camera Interface, MIPI DSI, CSI-2 and HSI, System Manager for power management, CF+, ATA I/F, 4-channel UART, 24-channel DMA, 4-channel Timers, General I/O Ports, 3-ch IIS, 2-ch S/PDIF, 2-ch CAN bus, IIC-BUS interface, 3-ch HS-SPI, USB Host 2.0, USB OTG 2.0 operating at high speed (480Mbps), SD Host & High Speed Multi-Media Card Interface and PLLs for clock generation.

POP (Package on Package) option with MCP is available for small form factor applications.

The SMDK_C100 consists of S5PC100X, bootable (NAND, OneNAND, NOR FLASH), LCD interface, two serial communication ports, configuration switches, JTAG interface, status LEDs and etc.




Figure 1 S5PC100X Functional Block Diagram

1.2 SMDK C100 FEATURES

The SMDK_C100 (S5PC100X Development Kit) highlights the basic system-based hardware design which uses the S5PC100X. It can evaluate the basic operations of the S5PC100X and assist in developing codes.

SMDK_C100 is manufactured by **MERITECH Co., Ltd** and company website is www.mcukorea.com

The features of SMDK_C100 include:

- Microcontroller : S5PC100X (16/32 bit RISC microcontroller, **ARM-CORTEX A8**)
- System Boot Device :
 - . Internal ROM (i-ROM)
 - . AMD 8Mbit NOR Flash 1EA (support halfword size boot ROM)
 - . SAMSUNG NAND Flash 1EA (with Socket)
 - . SAMSUNG OneNAND 1EA (External Board Option)
 - . SAMSUNG 8Mbit SRAM 1EA
 - . Modem Boot (External Connector)
- SDRAM : Memory Port-1: 256MB mDDR (128MB x 2, K4X1G163PC-L(F)E/GC6)
Note : Memory Port0: None (* Port 0 Bus is only for Static Memory Interface)
- TFT LCD & Touch panel interface : **Upto Resolution 1024 X 768**
- Compact FLASH / ATA interface
- SD/SDIO/MMC interface (Socket x 2)
- Digital Video & Audio : **HDMI 1.3 Video(720p) & S/PDIF 5.1 Channel Audio I/F**
- TV Out interface (**Component**, S-Video, Composite,)
- USB Host , USB OTG 2.0 interface
- High Speed SPI interface
- IIS/AC97/PCM Interface : WM9713, WM8580 For Audio CODEC
- General Camera Interface : Port-A and Port-B
- MIPI Camera Interface : **MIPI-CS12** (1Gbps/Lane Serial Communication)
- High Speed Serial MIPI Interface LCD : **MIPI-DSI** (1Gbps/Lane Serial Communication)
- High Speed MODEM Serial Interface : MIPI-HSI
- 2 port **CAN interface** : Ver.2.0
- Keypad interface
- Ethernet Interface : 10/100Mbps
- 2 port UART interface
- JTAG port
- **Module Connector (M1 ~ M5)**
 - . M1 (Module1): For GPS Daughter Board (UART0, SPI0) : Samsung GPD14B01 (SiRFSTAR III GSD3) (Optional)
 - . M2 (Module2): For Mobile TV Daughter Board (SPI1, IIC) or For HD Radio (SPI1, IIS for Module4)
 - ◆ Mobile TV: Samsung S5P4F31 (TBD, Optional)
 - ◆ HD Radio: SiPORT SD1010 (TBD, Optional) , Samsung (TBD, Optional)
 - . M3 (Module3): For Bluetooth Daughter Board (UART1, PCM for PMIC Audio Codec)
 - : Bluetooth: Atheros (TBD, Optional)



- . M4 (Module4): For Audio Daughter Board (AC97, IIS, IIC) : Audio: Wolfson WM8990
- . M5 (Module5): For LCD Module: Samsung WVGA 4.8" (Default), WSVGA, QVGA(Optional)
- . PMIC (200-FBGA Connector) : National Semiconductor PMIC(TBD, Optional)

2 SMDK C100 REAL VIEW

2.1 SMDK C100 CPU BOARD REAL VIEW




Figure 2 S5PC100X CPU BOARD TOP VIEW




Figure 3 S5PC100X CPU BOARD BOTTOM VIEW

2.2 SMDK C100 BASE BOARD REAL VIEW




Figure 4 S5PC100X BASE BOARD TOP VIEW




Figure 5 S5PC100X BASE BOARD BOTTOM VIEW

2.3 SMDK C100 LCD BOARD REAL VIEW



Figure 6 S5PC100X LCD BOARD TOP VIEW



Figure 7 S5PC100X LCD BOARD BOTTOM VIEW



CPU Board Power TREE (S5PC100)




Figure 9 S5PC100X CPU BOARD POWER DISTRIBUTION TREE

3.2 FUNCTIONAL BLOCK DIAGRAM




Figure 10 S5PC100X SMDK FUNCTIONAL BLOCK DIAGRAM



4 SMDK C100 SYSTEM CONFIGURATIONS

Perform the following steps to use SMDK_C100 board:

1. Select the Clock source

Please refer to 'CLOCK SOURCE SELECTION'

2. Set the Regulator mode (Fixed or Controllable voltage , VDD_ARM & VDD_INT)

Please refer to 'CONFIGURATION SWITCH DESCRIPTION IN CPU BOARD CFGB3' ,

3. Select the Boot mode and set by configuration switches (There are 5 boot modes)

Please refer to 'BOOT MODE SELECTION'

4. Set the each IP which you want to use by CPU and Base boards configuration switches

- For MMC

Please refer to 'CONFIGURATION SWITCH DESCRIPTION IN CPU BOARD'

- For CF CARD, LCD, Audio Controller, Audio Port(IIS,AC97,PCM), UART, IrDA, KEYPAD, Host I/F

Please refer to 'CONFIGURATION SWITCH DESCRIPTION IN BASE BOARD'

5. Check the Connector Please refer to 'CONNECTORS' , On Appendix

- JTAG, HDMI,MIPI-CSI, MIPI-DSI,USB, HS-SPI, MIPI HSI, SD/MMC, External MMC & MOVI-NAND & CF-ATA, External OneNAND,Camera I/F-A,PMIC External ROM bus, External MODEM I/F On CPU Board

- Component, Composite & S-video, S/PDIF, CAN2.0,Line in/ MIC in/ Speaker out, Ethernet, UART, Camera I/F-B, ADC, MMC, xD, PWM, External SPI, TFT LCD(Non-MIPI), Touch screen, , External LCD, External KEYPAD(QWERTY), Module 1 ~ 5 On Base Board

-

Configuration Switch (DIP Switch)



Off(Switch Open) → On (Switch Short)

4.1 PLL CLOCK SOURCE SELECTION

EXTCLK or X-TAL can be selected for the S5PC100X system clock by setting the XOM[0] values.

The Clock Source selection must be X-tal Clock (CFG2[1] on CPU Board).

Description	CFG2[1], (XOM[0])
X-tal Clock (12 ~20MHz)	OFF (Logic "0")
External Oscillator Clock (USB Clock)	ON (Logic "1")

4.2 BOOT MODE SELECTION

4.2.1 Switch Configuration

A. Set CFG2 on CPU board to select Internal ROM Boot

Description	CFG2[5:1] *CFG2[6] : N.C				
	[5]	[4]	[3]	[2]	[1]
Internal ROM Boot for NAND Flash	OFF	OFF	OFF	OFF	OFF
Internal ROM Boot for OneNAND	OFF	OFF	OFF	ON	OFF
Internal ROM Boot for Movi / i-NAND	OFF	OFF	ON	OFF	OFF
Internal ROM for (NOR)	OFF	OFF	ON	ON	OFF
NOR FLASH (1 st & 2 ND BOOT)	OFF	ON	X	X	OFF

B. Set CFG3 on CPU board to select

Description	CFG3[4:1]			
	[4]	[3]	[2]	[1]
☛ Case 1 : CFG2 : Internal ROM Boot for NAND Flash				
NAND Flash, 512-byte page, 3 Addr. Cycle	OFF	OFF	OFF	OFF
Normal NAND, 512-byte page, 4 Addr. Cycle	OFF	ON	OFF	OFF
Large Page NAND, 2K-byte page, 4 Addr. Cycle	OFF	OFF	ON	OFF
Large Page NAND, 2K-byte page, 5 Addr. Cycle	OFF	OFF	ON	OFF
Large Page NAND, 4K-byte page, 4 Addr. Cycle	OFF	ON	ON	ON
Large Page NAND, 4K-byte page, 5 Addr. Cycle	OFF	ON	ON	ON
☛ Case 2 : CFG2 : Internal ROM Boot for Movi / i-NAND				
Movi-NAND (MMC)	OFF	X	X	OFF
i-NAND (SD)	OFF	X	X	ON
Description	CFG[6:5]			
	[6]	[5]		
ECC Encryption	x	OFF		
No ECC Encryption	x	ON		



Use PLL	OFF	x
No Use PLL	ON	x

4.3 CONFIGURATION SWITCH DESCRIPTION IN CPU BOARD

4.3.1 CFGB3: FOR USING Controllable Regulator (ARM/INT)


CFGB3 Switch is used to enable shift register output. If the shift register is not enabled, the default value of the VDD_1.2V_ARM/INT is determined with external pull up/down resistors. Below is the description of the Regulator Control Signal.

LTC3714 (U22-For ARM, U25-For INT) @ CFGB3[1]: ON & 'XEINT4(GPH04)': Logic "0"					Dynamic Voltage scaling
VID4	VID3	VID2	VID1	VID0	
0	1	0	0	1	1.300V
0	1	0	1	0	1.250V
0	1	0	1	1	1.200V
0	1	1	0	0	1.150V
0	1	1	0	1	1.100V
0	1	1	1	0	1.050V
0	1	1	1	1	1.000V
1	0	0	0	0	0.975V
1	0	0	0	1	0.950V
1	0	0	1	0	0.925V
1	0	0	1	1	0.900V
1	0	1	0	0	0.875V
1	0	1	0	1	0.850V
1	0	1	1	0	0.825V
1	0	1	1	1	0.800V
1	1	0	0	0	0.775V
1	1	0	0	1	0.750V
1	1	0	1	0	0.725V
1	1	0	1	1	0.700V



4.3.2 CFG1: SELECTION FOR MAIN POWER SUPPLY

CFG1	
<input checked="" type="checkbox"/> 	Use OnBOARD Regulator
<input type="checkbox"/> 	Use PMIC



4.3.3 CFGB1: HDMI I2C Channel

CFGB1	Description
[1]	OFF(Logic"0"): ENABLE ON(Logic"1"): DISABLE
[2]	N.C

4.3.4 CFGB2: SELECTION BETWEEN CAM-A AND MMC1/2

CFGB2		Description
[1]	[2]	
ON(Logic"0")	OFF(Logic"1")	MMC1 == MMC2
OFF(Logic"1")	OFF(Logic"1")	MMC1 == CAM-A,

4.4 CONFIGURATION SWITCH DESCRIPTION IN BASE BOARD

4.4.1 CFGB1: SROM BANK0 CHIP SELECTOR

CFGB1 component is used to select devices as SROM BUS I/F 0(B_M0CSnx).

<i>Description</i>	CFGB1		
	[3]	[2]	[1]
NOR (AMD) Flash	OFF	OFF	ON
SRAM	OFF	ON	OFF
External Device	ON	OFF	OFF

4.4.2 CFGB2: SROM BANK1 CHIP SELECTOR

CFGB2 component is used to select devices as SROM BUS I/F 1(B_M0CSn2/FCSn0).

<i>Description</i>	CFGB2			
	[4]	[3]	[2]	[1]
XD card	OFF	OFF	OFF	ON
NAND	OFF	OFF	ON	OFF
External Device	OFF	ON	OFF	OFF
Ethernet	ON	OFF	OFF	OFF

4.4.3 CFGB3: SROM BANK2 CHIP SELECTOR

CFGB3 component is used to select devices as SROM BUS I/F 2(B_M0CSn3/FCSn1).

<i>Description</i>	CFGB3			
	[4]	[3]	[2]	[1]
XD card	OFF	OFF	OFF	ON
NAND	OFF	OFF	ON	OFF
External Device	OFF	ON	OFF	OFF
Ethernet	ON	OFF	OFF	OFF



4.4.4 CFGB4: SRAM BANK3 CHIP SELECTOR

CFGB4 component is used to select devices as SRAM BUS I/F 3(B_Xm0CSn4/FCSn2/CFCSn0).

Description	CFGB4			
	[4]	[3]	[2]	[1]
SRAM	OFF	OFF	OFF	ON
NAND Flash	OFF	OFF	ON	OFF
CF Card	OFF	ON	OFF	OFF
Ethernet	ON	OFF	OFF	OFF

4.4.5 CFGB5: SRAM BANK4 CHIP SELECTOR

CFGB5 component is used to select devices as SRAM BUS I/F 4(B_Xm0CSn5/FCSn3/CFCSn1).

Description	CFGB5			
	[4]	[3]	[2]	[1]
SRAM	OFF	OFF	OFF	ON
NAND Flash	OFF	OFF	ON	OFF
CF Card	OFF	ON	OFF	OFF
Ethernet	ON	OFF	OFF	OFF

4.4.6 CFG8: CF CARD TRANSFER MODE SELECTOR

CFG8 component is used to select CF transfer mode.

Description	CFG8	
	[2]	[1]
Direct Mode	N.C	OFF
Indirect Mode	N.C	ON

Note.

* Direct Mode: Mode which has Control signal for CF through the dedicated CF pin

* Indirect Mode: Mode which has Control signal for CF through the EBI

4.4.7 CFG1: COM PORT CONTROL

CFG1 component is used to control COM Port.

<i>Description</i>	CFG1		
	[3]	[2]	[1]
UART1	X	X	OFF
UART2	OFF	OFF	ON
UART3	ON	ON	ON
IrDA(U2)	OFF	X	X

4.4.8 CFG2: KEYPAD/ CAM B CONTROL

CFG2 component is used to control Keypad.

<i>Description</i>	CFG2	
	[2]	[1]
Disable	OFF	OFF
KEYPAD	OFF	ON
CAMERA B	ON	OFF

4.4.9 CFG3: KEYPAD/ CAN2.0 CONTROL

CFG3 component is used to control Keypad.

<i>Description</i>	CFG3	
	[2]	[1]
Disable	OFF	OFF
KEYPAD	ON	OFF
CAN 2.0	ON	ON

4.4.10 CFG4: S/PDIF SELECTOR

CFG4 component is used to SPDIF.

<i>CFG1</i>	<i>Description</i>
-------------	--------------------

[1]	Channel-B1
[2]	Channel-B2

4.4.11 CFG5: WM8580 MASTER CLOCK SELECTOR

CFG5 component change source of WM8580 Master clock.

<i>CFG5</i>	<i>DESCRIPTION</i>
[1]	CDCLK of I2S0 is source of WM8580 Master clock
[2]	CDCLK of I2S1,2 is source of WM8580 Master clock
[3]	CLOCK of External is source of WM8580 Master clock.

4.4.12 CFG6: AUDIO CONNECTOR

CFG6 component is used to select S5PC100X Audio port.

<i>CFG6</i>	<i>Description</i>	
	<i>ON</i>	<i>OFF</i>
[1] : Speaker	WM9713(AC97)	WM8580(IIS)
[2] : Mic		
[3] : Line In		
[4] : Reserved	-	-

4.4.13 CFG7: AUDIO SELECTOR

CFG7 component is used to select S5PC100X Audio port.

<i>CFG7</i>	<i>Description</i>	
	<i>ON</i>	<i>OFF</i>
[1]	Audio1 Enable	Audio1 Disable
[2]	Audio1: WM8580 IIS/PCM	Audio1: WM9713 AC97
[3]	Audio2 Enable	Audio2 Disable

[4]	Audio1: WM8580 IIS/PCM	Audio1: WM9713 IIS/PCM
-----	------------------------------	------------------------------

4.5 JUMPER SETTING CONFIGURATION

J1: Alternative Chip selection (Flash CS0/ OneNAND CS0)

1 2	[] [] []	CS0 For Flash memory
2 3	[] [] []	CS0 For OneNAND

J2: Alternative Chip selection (Flash CS1/ OneNAND CS1)

1 2	[] [] []	CS1 For Flash memory
2 3	[] [] []	CS1 For OneNAND

J3: Level Shifter Power supply

1 2	[] [] []	VDD_SYS (3.3V)
2 3	[] [] []	VDD_MEM0 (1.8V)

J4: Alternative Chip Selection For SROM Memory Port 0

-
-

1		CS0
2		CS1

5 Appendix : CONNECTORS

5.1 CPU BOARD

5.1.1 JTAG




Figure 11 JTAG Connector

Note.

*

5.1.2 USB

One USB ports A-type (CON7, HOST) and one USB OTG port mini AB-type (CON6) are supported by the SMDK_C100.




Figure 12 One USB ports & OTG port

5.1.3 SPI

Two IEEE-1394 connectors are used as SPI connector.




Figure 13 SPI port

5.1.4 MIPI HSI

FPC cable is used as a MIPI HSI connector




Figure 14 MIPI-HSI port

5.1.5 SD host (Ver2.0) /MMC interface

SD/MMC is provided by the _C100 and SD card sockets are supported in the SMDK_C100.




Figure 15 SD/MMC port




Figure 16 MMC port

5.1.6 EXTERNAL ONE-NAND connector

External connector is supported for connecting ONE_NAND external board

One NAND Connector




Figure 17 One NAND memory port

5.1.7 Camera Interface –A Connector

SMDK_C100 provides Camera Interface Connector.




Figure 18 Camera Interface -A port

5.1.8 PMIC connector

SMDK_C100 provides 200-FBGA Connector for PMIC Module Board.




Figure 19 PMIC Connector

5.1.9 HDMI Connector







Figure 20 HDMI VIDEO CONNECTOR

5.1.10 MIPI-CSI



Samsung 5MP camera - S5K3E1GX
MIPI-CSI Camera Module Interface

Figure 21 MIPI-CSI port

5.1.11 MIPI-DSI




Figure 22 MIPI-DSI port

5.1.12 TFT LCD I/F CONNECTOR

TFT LCD FPC Cable Interface (MODULE Board)




Figure 23 TFT-LCD CONNECTOR

5.2 BASE BOARD

5.2.1 Component, Composite & S-VIDEO Connector

SMDK_C100 provides Component(Y-Pb-Pr), Composite(Y) & S-Video(Y/C) output connector




Figure 24 Component, Composite & S-VIDEO Connector

5.2.2 LINE IN, MIC IN & SPEAKER OUT Connector

SMDK_C100 provides LINE IN, MIC IN and SPEAKER OUT as an audio connector.




Figure 25 Audio Line In, Mic In & Speaker Out Connector

5.2.3 ETHERNET CONNECTOR

SMDK_C100 provides Ethernet 100Mbps (CON20) connector.




Figure 26 100Base-T Ethernet Socket

5.2.4 UART interface

The S5PC100X UART unit provides three independent asynchronous serial I/O (SIO) ports including IrDA.

In SMDK_C100 board, COM1 port is only used for UART0. No jumper setting is required. You



can change UART by setting related jumpers.




Figure 27 UART Sockets

5.2.5xD Picture Card Connector

SMDK_C100 provides xD Picture Card Connector.




Figure 28 xD Picture Card Socket




Figure 2 Camera Interface –B Connector

5.2.9 CAN 2.0 Interface

CAN 2.0 Interface (1Mbps)





Figure 4 CAN 2.0 Port

5.2.10 S/PDIF 5.1 Channel Audio Interface



S/PDIF Audio Out

Figure 5 S/PDIF Audio Port

5.3 EXTERNAL CONNECTOR INTERFACE

5.3.1 ROM BUS Interface




Figure 6 ROM BUS INTERFACE

5.3.2 HOST/MODEM INTERFACE




Figure 7 HOST/MODEM INTERFACE

5.3.3 EXTERNAL KEYPAD CONNECTOR






Figure 8 External Keypad Connector

5.3.4 MODULE1: FOR GPS DAUGHTER BOARD



5.3.5 MODULE2: FOR MOBILE TV, HD RADIO DAUGHTER BOARD



5.3.6 MODULE3: FOR BLUETOOTH DAUGHTER BOARD




Figure 11 MODULE3 : For Bluetooth Module

5.3.7 MODULE4: FOR AUDIO DAUGHTER BOARD




Figure 12 MODULE4 : For Audio Module

5.3.8 MODULE5: FOR LCD BOARD (with Touch Screen)

TFT LCD controllers are equipped in the S5PC100X. TFT LCD, touch panel and LCD backlight driver are supported in the SMDK_C100.

Part Name	Default LCD	Option #1	Option #2
Model Name	LMS480KF02	LTS480WS-C01	LTS222QVF0
Pannel Size	4.8"	4.8"	2.2"
#pixels	800x480 (WVGA)	1024x600 (WSVGA)	240x320 (QVGA)
I/F type	24bit RGB	6bit/3Lane LVDS	RGB Serial / I-80

RGB(24Bit) Parallel Interface




Figure 13 4.8 inch WVGA LCD I/F

RGB serial(18BPP) Interface & I80 Interface [Main,Sub]

* Note: Samsung LCD LTS222QV-F01 (2.22")

Logic Voltage : 1.7/2.8/3.3V
 DC/DC Voltage : 2.5/2.8/3.3V
 Current : Stand-by 30 ~ 100uA
 Current : Still 5 ~ 50mA
 Current : Full 6 ~ 10mA




Figure 14 2.2 inch QVGA LCD I/F




Figure 15 4.8 inch WSVGA LCD I/F

6 SMDK SCHEMATIC REVISION HISTORY

This document contains information of corrected points on the schematic of SMDK_C100. The corrected points are highlighted in pink-circled in schematic of SMDK_C100 Rev 0.1

Boards	Page	Contents	Corrected points (ECN)
CPU Board			
Base Board			
LCD Board			



7 SMDK SCHEMATIC

There are 3 parts of SMDK Schematic.

1. CPU Board Rev0.0 (SMC823A)
2. Base Board Rev0.0 (SMC824A)
3. LCD Board Rev0.0 (SMC825A)



S5PC100_SMDK_ S5PC100_SMDK_ S5PC100_SMDK_
CPU_BD_SCHEMABASE_BD_SCHEMLCD_DB_SCHEM

Note. It is easy to find schematic parts by using **Bookmarks** on PDF