WF121 Wi-Fi MODULE

DATA SHEET

Thursday, 24 May 2012 Version 1.0



Copyright © 2000-2012 Bluegiga Technologies

All rights reserved.

Bluegiga Technologies assumes no responsibility for any errors which may appear in this manual. Furthermore, Bluegiga Technologies reserves the right to alter the hardware, software, and/or specifications detailed here at any time without notice and does not make any commitment to update the information contained here. Bluegiga's products are not authorized for use as critical components in life support devices or systems.

The WRAP, Bluegiga Access Server, Access Point and iWRAP are registered trademarks of Bluegiga Technologies.

The *Bluetooth* trademark is owned by the Bluetooth SIG Inc., USA and is licensed to Bluegiga Technologies. All other trademarks listed herein are owned by their respective owners.

VERSION HISTORY

Version	Comment
1.0	First version

TABLE OF CONTENTS

1	Ord	ering Information	7
2	Pin-	out and Terminal Descriptions	8
3	Pow	ver control	. 10
	3.1	Power supply requirements	. 10
	3.2	Reset	. 10
4	Micı	ocontroller	. 11
5	Inte	rfaces	. 12
	5.1	General Purpose I/O pins	. 12
	5.2	Serial ports	. 12
	5.3	I ² C/SPI	. 13
	5.4	USB On-The-Go	. 13
	5.5	Ethernet	. 14
	5.6	Analog inputs	. 15
	5.7	Timers	. 15
	5.8	Parallel master port	. 15
	5.9	Microcontroller programming interface	. 15
	5.10	RF Debug Interface	. 16
	5.11	Bluetooth co-existence	. 16
	5.12	CPU Clock	. 17
	5.13	32.768 kHz External Reference Clock	. 18
6	Exa	mple schematic	. 19
7	802	.11 Radio	. 20
	7.1	Wi-Fi Receiver	. 20
	7.2	Wi-Fi Transmitter	. 20
	7.3	Antenna switch for Bluetooth coexistence	. 20
8	Firm	nware	. 21
9	Hos	t interfaces	. 22
	9.1	UART	. 22
	9.2	USB	. 22
	9.3	SPI	. 22
1() E	Electrical characteristics	. 23
	10.1	Absolute maximum ratings	. 23
	10.2	Recommended operating conditions	. 23
	10.3	Input/output terminal characteristics	. 24
	10.4	Digital	. 24
	10.5	Reset	. 24
	10.6	Power consumption (preliminary)	. 25

11	RF Characteristics	26
12	Physical dimensions	28
13	Layout guidelines	29
13.1	WF121-E	29
13.2	WF121-N	29
13.3	WF121-A	29
13.4	Thermal considerations	30
13.5	EMC considerations	30
14	Soldering recommendations	32
15	Certifications	33
15.1	CE	33
15.2	FCC	33
15.3	IC	33
15.4	TELEC	33
16	Qualified Antenna Types for WF111-E	34
17	Contact information	35

DESCRIPTION

WF121 is a self-contained Wi-Fi module providing a fully integrated 2.4GHz 802.11 b/g/n radio and a 32-bit microcontroller (MCU) platform, making it an ideal product for embedded applications requiring simple, low-cost and low-power wireless TCP/IP connectivity. WF121 also provides flexible interfaces for connecting to various peripherals.

WF121 allows end user applications to be embedded onto the on-board 32-bit microcontroller either using a simple BGScriptTM scripting language or for more sophisticated applications; ANSI C-language. This cuts out the need of an external MCU and allows the development of smaller and lower-cost products. However WF121 can also be used in modem-like mode in applications where the external MCU is needed.

With an integrated 802.11 radio, antenna, single power supply, and regulatory certifications, WF121 provides a low-risk and fast time-to-market for applications requiring Internet connectivity. This combined with Bluegiga's excellent customer service will turn your Internet-of-Things applications into reality.

APPLICATIONS:

- PoS terminals
- RFID and laser scanners
- Wi-Fi internet radios and audio streaming products
- Wireless cameras
- Video streaming
- Portable navigation devices
- Portable handheld devices
- Wi-Fi medical sensors
- Wireless picture frames

KEY FEATURES:

- 2.4GHz band IEEE 802.11 b/g/n radio
- Excellent radio performance:
 - TX power: +17 dBm
 - RX sensitivity: -97 dBm
- Host interfaces:
 - 20Mbps UART
 - USB on-the-go
- Peripheral interfaces:
 - GPIO, AIO and timers
 - I2C, SPI and UART
 - Ethernet
- Embedded TCP/IP and 802.11 MAC stacks:
 - IP, TCP, UDP, DHCP and DNS protocols
 - BGAPI host protocol for modem like usage
 - BGScriptTM scripting language or native C-development for selfcontained applications
- 32-bit embedded microcontroller
 - 80Mhz, 128kB RAM and 512kBFlash
 - MIPS architecture
- Temperature range: -40°C +85°C
- Fully CE, FCC and IC qualified

PHYSICAL OUTLOOK:



WF121-A

1 Ordering Information

Product code	Description
WF121-A	WF121 module with integrated antenna
WF121-E	WF121 module with U.FL connector
WF121-N	WF121 module with RF pin. Non-standard product, so minimum order quantity applies. Please contact: sales@bluegiga.com
DKWF121	WF121 development kit

2 Pin-out and Terminal Descriptions




Figure 1: WF121 pinout

Pad number	Function	Description
9	VDD_3.3V	Module power supply
8	VDD_PA	RF power amplifier power supply
1, 16, 26, 45, 48, 50	GND	Ground, connected together internally but should all be connected directly to a solid ground plane
51	GNDPAD	Thermal ground pad, should be soldered to a directly to a solid ground plane for improved thermal conductance
40	BT_RF	Bluetooth coexistence antenna connection, connect to ground through a 51ohm resistor if coexistence is not used
49	ANT	Antenna connection pad in N variant of the module, in other variants not connected
25	VBUS	USB VBUS input
13	MCLR	Module reset, also used for programming using a Microchip tool. Internal pull-up, can be left floating or connected to ground through a 100nF capacitor for delayed power-up reset (note: Microchip ICSP programming tools will not work with a capacitor)

Table 1: Single function pad descriptions

PAD#	GPIO	I2C	SPI	UART	Ethernet	Timer	USB	Analog	Prog.	Parallel	Other
2	RB15 CN12				EMDC	OCFB		AN15		PMA0 PMLL	
3	RE0				ERXD1					PMD0	
4	RE1				ERXD0					PMD1	
5	RE2				ECRSDV					PMD2	
6	RE3				EREFCLK					PMD3	
7	RE4				ERXERR					PMD4	
10	RE5				ETXEN					PMD5	
11	RE6				ETXD0					PMD6	
12	RE7				ETXD1					PMD7	
14	RB1 CN3							AN1	PGEC1		
15	RB0 CN2							AN0	PGED1	PMA6	
17	RB8		SS4	U2CTS U5RX		C1OUT		AN8			
18	RF3						OTG_ID				
19	RB14		SCK4	U2RTS U5TX				AN14		PMA1 PMALH	
20	RB13							AN13	TDI	PMA10	
21	RB12							AN12	TCK	PMA11	
22	RB11							AN11	TDO	PMA12	
23	RB10							AN10	TMS	PMA13	
24	RB5 CN 7						VBUSON	AN5			
27	RG3						D-				
28	RG2						D+				
29	RD3	SCL3	SDO3	U1TX		OC4					
30	RC12										OSC1
31	RC15										OSC2
32	RD2	SDA3	SDI3	U1RX		OC3					
33	RC13 CN 1										SOSCI
34	RC14 CN0					T1CK					sosco
35	RF4 CN17	SDA5	SDI4	U2RX						PMA9	
36	RF5 CN18	SCL5	SDO4	U2TX						PMA8	
37	RD11 INT4					IC4				PMA14	BT_PERIODIC
38	RD0 INT0					OC1					WLAN_DENY
39	RD4					IC5/OC5				PMWR	BT_STATUS
41	RD5									PMRD	BT_ACTIVE
42	RD6 CN15				ETXERR						
43	RD7 CN16										
44	RD9 INT2	SDA1	SS3	U1CTS U4RX		IC2					
46	RD10 INT3	SCL1				IC3				PMA15	
47	RD1		SCK3	U1RTS U4TX	EMDIO	OC2					

Table 2: Multifunction pad descriptions

Note: 5V tolerant pads are marked with orange. CN pins support pull-up, pull-down and GPIO notifications

3 Power control

3.1 Power supply requirements

WF121 is designed to operate with a 3.3V nominal input voltage supplied to two module pads. The VDD_3.3V pad can be fed with a voltage between 2.3V and 3.6V and is used to power the internal microcontroller. The VDD_PA pad can be supplied with a voltage between 2.7V and 4.8V and supplies the RF power amplifier and the internal switch-mode converter powering the WiFi digital core.

In lithium battery powered applications, VDD_PA can be connected directly to the battery, while a regulator is needed to supply the VDD_3.3V with a lower voltage, as needed by the design.

The VDD_PA supply should be capable of providing at least 350mA, though the average consumption of the module will be much less than that. The VDD_3.3V supply will draw a peak current of less than 100mA, not including current drawn from the GPIO pins. The PA supply should preferably be bypassed with a 10 to 100µF capacitor to smooth out the current spikes drawn by the Wi-Fi power amplifier. External high frequency bypassing is not needed, the module contains the needed supply filtering capacitors.

While the Wi-Fi power saving modes reduce the idle consumption to very low levels, it may in some applications be useful to reduce the consumption even further. For this purpose, the Wi-Fi part of the module can be fully shut down internally by disabling the internal switch mode converter to minimize power consumption, though restarting it requires a new WiFi core power-up initialization. This will usually take several seconds, but in applications where a connection is required only once a few minutes or this might not be an issue while the reduced consumption can be very valuable.

The WF121 module automatically applies various power saving modes during operation to minimize average power consumption.

3.2 Reset

WF121 can be reset by the MCLR-pin (active low), system power up, the internal brown-out detector or the internal watchdog timer.

4 Microcontroller

WF121 contains a Microchip PIC32-series microcontroller with a MIPS M4K core. At a maximum clock frequency of 80 MHz the core can reach a performance of 125 DMIPS while keeping low power consumption.

The microcontroller used in WF121 contains 512kB of Flash memory and 128kB of SRAM.

Most peripheral features are directly provided by the microcontroller and for low level information and detailed descriptions please refer to the material and datasheets of the PIC32MX695H.

5 Interfaces

5.1 General Purpose I/O pins

To see which GPIOs are multiplexed with which features, please refer to Table 2.

.WF121 contains a number of pads that can be configured to be used as general purpose digital IO's, analog inputs or for various built-in functions. Provided functions include a Full Speed USB-OTG port, three I2C-ports, two SPI-ports, two to four UART's, Ethernet MAC with RMII connection and various timer functions. Some of the pads are 5V tolerant. All GPIO pads can drive currents of up to +/- 25 mA.

Four pins are available for implementing a coexistence scheme with a Bluetooth device. The exact order and function as well as the coexistence system desired is software configurable, with the default pad bindings shown in Table 3 for a Unity-3e+ coexistence scheme. If the pads are bound to WiFi chip pins, the CPU pins associated with the pads must be set to inputs.

5.2 Serial ports

Pad number	UART 1	UART 2	UART 4	UART 5
17		CTS		RX
21		RTS		TX
29	TX			
32	RX			
35		RX		
36		TX		
44	CTS		RX	
47	RTS		TX	

Table 3: Serial port pads

Two UART's are provided with RTS/CTS-handshaking. If handshaking is not needed, up to four UART's can be implemented. Speeds up to 20 Mbps are possible, but the higher bit rates might require the use of an external crystal for sufficient clock accuracy. The serial ports can also be used as host connections when using an external microcontroller.

To see what other functions are present on the same pins, please refer to Table 2.

.

5.3 I²C/SPI

Pad number	I ² C	SPI
17		SS4 – Slave select SPI 4
19		SCK4 - Clock SPI 4
29	SCL3 – Clock I ² C 3	SDO3 – Data out SPI 3
32	SDA3 – Data I ² C 3	SDI3 – Data in SPI 3
35	SDA5 – Data I ² C 5	SDI4 – Data in SPI 4
36	SCL5 – Clock I ² C 5	SDO4 – Data out SPI 4
46	SCL1 – Clock I ² C 1	
44	SDA1 – Data I ² C 1	SS3 – Slave select SPI 3
47		SCK3 – Clock SPI 3

Table 4: Pads for I2C and SPI

Up to three I²C-ports and up to two SPI ports can be implemented, mostly multiplexed on the same pins together and with the UART signals. The I²C ports support 100 kHz and 400 kHz speed specifications, while the SPI can be operated at up to 40 Mbps. The SPI ports are also available for use as a host connection for use with an external microcontroller.

To see what other functions are present on the same pins, please refer to **Table 2**.

5.4 USB On-The-Go

Pad number	Function	Description
18	OTG_ID	USB-OTG mode identify line
25	VBUS	USB bus supply input
27	D-	Data +
28	D+	Data -
26	VBUSON	USB bus supply switch enable in host mode

Table 5: USB pads

The module contains a USB-OTG system with an integrated transceiver. Full Speed (12 Mbps) USB 2.0 profile is supported in device mode, while the host system can operate in Low Speed and Full Speed modes. For host use an external switch can be implemented to provide switched power for the connected device. Pad number 26 can be dedicated to control this switch. The USB device can be used as a host connection, although the embedded (simplified) USB-OTG may not be able to support every kind of USB system, like hubs.

Using the USB connection requires an external crystal for sufficient clock accuracy. Other functions are present on the same pins; please refer to **Table 2** for details.

5.5 Ethernet

Pad number	Function	Description
2	EMDC	Management bus clock
3	ERXD1	Receive data 1
4	ERXD0	Receive data 0
5	ECRSDV	Receive data valid
6	EREFCLK	Reference clock
7	ERXERR	Receive error
10	ETXEN	Transmit enable
11	ETXD0	Transmit data 0
12	ETXD1	Transmit data 1
46	ETXERR	Transmit error
47	EMDIO	Management bus data

Table 6: Ethernet pads

An RMII interface to an external Ethernet PHY is available. The PHY should supply EREFCLK with a 50 MHz RMII reference clock. Other functions are present on the same pads; please refer to **Table 2** for details.

5.6 Analog inputs

Pad number	Function
2	AN15
14	AN1
15	AN0
17	AN8
19	AN14
20	AN13
21	AN12
22	AN11
23	AN10
24	AN5

Table 7: ADC pads

The microcontroller provides a 10-bit Analog to digital converter (ADC) with sampling speeds up to 1MSps. The measurement can be done on any of the input pins listed in the table above. For further information see the PIC32MX695H data sheet and related documents.

5.7 Timers

The module processor contains 5 timers with various functions including capture & compare. For more information see the PIC32MX695H data sheet.

5.8 Parallel master port

An 8-bit master/slave port is also available for transferring parallel data at a high speed to or from the module microcontroller. For more information, see PIC32MX695H data sheet.

5.9 Microcontroller programming interface

Pad number	Pad function	Description
13	MCLR	Reset
14	PGEC1	Programming Clock
15	PGED1	Programming Data
20	TDI	JTAG Test Data In
21	тск	JTAG Test Clock

Bluegiga Technologies Oy

22	TDO	JTAG Test Data out
23	TMS	JTAG Test Machine State

Table 8: Programming and JTAG pads

A programming connection (PGEC1, PGED1, MCLR) is provided to allow device re-flashing using a Microchip tool. A JTAG connection is also provided which can be used for system debugging purposes or device programming. The JTAG supports basic boundary scans but not CPU core debugging.

5.10 RF Debug Interface

Pad number	Pad function	Description
52	SPI_MISO	RF Debug data out
53	SPI_CLK	RF Debug clock
54	SPI_MOSI	RF Debug data in
55	SPI_CS	RF Debug chip select

Table 9: RF Debug SPI pads

Four pads are provided for the debug interface of the WiFi chipset in the module bottom. This is meant for RF calibration and testing during module production and product certification measurements. These should in most applications be left unconnected, but should be taken into account when doing the application board layout. Avoid placing vias or signals without a solder mask under these pads.

5.11 Bluetooth co-existence

Bluetooth coexistence systems allow co-located WiFi and Bluetooth devices to be aware of each other and to avoid simultaneous transfers that would degrade link performance. There are many ways of implementing such connections, from host driver negotiated channel and time sharing, to hardware signalling between the two devices. WF121 supports a number of different coexistence schemes with up to 4 control lines for hardware communication between the two devices.

WiFi and Bluetooth may also use separate antennas, or share a single antenna through a switch and/or a coupler. With a shared antenna, usually two additional signals are needed to control the front end switch. WF121 contains an internal switch for separating WiFi and Bluetooth transmissions as well as a shared low noise amplifier that allows both WiFi and Bluetooth to receive simultaneously using the same amplifier.

For use with CSR-based Bluetooth (BC4 to BC6 with firmware version 21 or later, BC7 and onwards with all versions), Unity-3e+ is recommended as the coexistence scheme. Unity-3e is an enhanced version of the 3-wire Unity-3 –scheme that uses tighter timings and uses the three control lines also for antenna switch control, removing the need for the two separate switch control lines which with the limited number of coexistence capable signals in WF121 would limit the supported coexistence schemes to just 2-wire schemes. Unity-3e+, or Unity-3e with Unity+ adds an additional BT_PERIODIC signal to communicate the need for a periodic transmission from the Bluetooth to the WiFi, allowing a guaranteed low-latency throughput for certain Bluetooth applications despite high WiFi usage. This allows reliable audio connections that would otherwise suffer from the WiFi's higher priority.

Pad number	Function
37	BT_PERIODIC
38	WLAN_DENY
39	BT_STATUS
41	BT_ACTIVE

Table 10: Bluetooth co-existence interface

Industry standard 2-wire, 3-wire and 4-wire, as well as Unity-2, Unity-3, Unity-4, Unity-3e and Unity-coexistence schemes are supported and the associated signals can be assigned to the GPIO pads. In default mode these pins are tied to CPU GPIO functions. Antenna sharing is possible with 2-wire, Unity-2 and Unity-3e/3e+ schemes.

For more detailed information about implementing co-existence, see WF111 datasheet.

5.12 CPU Clock

Pad number	Function	Description
30	OSC1	External crystal input
31	OSC2	External crystal output

Table 11: Clocking pads

WF121 uses an internal 26 MHz crystal as the WiFi reference clock. The internal processor uses an integrated 8MHz RC oscillator and associated phase locked loop (PLL) to create its clock signals, but cannot share the internal crystal-stabilized WiFi clock. The internal CPU uses a PLL to create an 80MHz core clock.

To use the USB functionality an external crystal and the associated capacitors must be implemented on the application board to provide a sufficiently accurate clock. A crystal with its associated capacitors can be connected to pads OSC1 and OSC2. If an external crystal is not needed, these pads are available for GPIO use. The USB clock synthesizer requires an internal reference frequency of 4MHz, so the crystal for USB use must be a multiple of 4MHz.

An external oscillator can also be used to generate the CPU clock frequency. The voltage levels should be 3.3V logic level.

Note: The present WF121 default firmware only supports 8MHz crystals or oscillators.

The internal clock divider generating the reference frequency for the internal PLL's cannot be changed by the firmware, and to support automatic switchover between the internal RC oscillator and the external crystal, the default firmware needs an 8MHz clock. A custom firmware can be ordered with support for desired frequencies for easier crystal availability, for achieving desired UART baud rates and other applications.

The Ethernet connection requires the external PHY to provide the 50MHz RMII reference clock. A crystal is not required for the module CPU for Ethernet operation.

5.13 32.768 kHz External Reference Clock

Pad number	Function	Description
35	SOSCI	External 32.768 kHz crystal input
36	sosco	External 32.768 kHz crystal output

Table 12: Slow clock

The module contains integrated RC oscillators for sleep timing, one in the WiFi chipset, one in the CPU. The sleep clocks are used to periodically wake up the module while in power save modes. If more accurate timing is required, an external 32.768 kHz crystal and the associated capacitors can be placed to pads SOSCI and SOSCO. If an accurate sleep clock is not needed, the pads are available for GPIO use.

An external oscillator can also be used to generate the sleep clock. The voltage levels should be 3.3V logic level.

This low frequency clock is shared for both the CPU and the WiFi chipset. The default WiFi configuration uses only the internal oscillator, if support for a crystal stabilized WiFi sleep clock is required, please contact Bluegiga technical support.

The Wi-Fi packet timing during active data transfer is derived from the internal 26MHz crystal and so is unaffected by the tolerances of the sleep clock.

6 Example schematic




Figure 2: Minimal system required for UART host connection

7 802.11 Radio

7.1 Wi-Fi Receiver

The receiver features direct conversion architecture. Sufficient out-of-band blocking specification at the Low Noise Amplifier (LNA) input allows the receiver to be used in close proximity to GSM and WCDMA cellular phone transmitters without being desensitized. High-order baseband filters ensure good performance against in-band interference.

7.2 Wi-Fi Transmitter

The transmitter features a direct IQ modulator. Digital baseband transmit circuitry provides the required spectral shaping and on-chip trims are used to reduce IQ modulator distortion. Transmitter gain can be controlled on a per-packet basis, allowing the optimization of the transmit power as a function of modulation scheme.

The internal Power Amplifier (PA) has a maximum output power of +15dBm for IEEE 802.11g/n and +17dBm for IEEE 802.11b. The module internally compensates for PA gain and reference oscillator frequency drifts with varying temperature and supply voltage.

7.3 Antenna switch for *Bluetooth* coexistence

WF111 supports sharing the integrated antenna or antenna connector with a *Bluetooth* device through the BT_RF pad. The module contains a bypass switch to route the *Bluetooth* signal directly to the antenna, and supports using the internal LNA for *Bluetooth* reception. The switch is controlled through the coexistence interface.

8 Firmware

WF121 incorporates firmware which implements a full TCP/IP stack and Wi-Fi management. Exact features will depend on the firmware version used. Please see the documentation of the firmware for exact details.

There are three main ways to use the module: Host controlled, script controlled or native application controlled.

Host controlled means an external host is physically connected to the module and it sends simple commands to the module and one of several different host interfaces can be used. The module provides high level APIs for managing Wi-Fi as well as data connections. Bluegiga provides a thin API layer (BGLib) written in ANSI C for the host which can take care of creating and parsing the messages sent over the transport. For evaluation purposes GUI tools and a library for python are also provided.




Figure 3: WF121 software

Data can be routed either through the API or through another physical interface. For example if the first UART is used for sending and receiving command events, a TCP/IP socket can be bound to the second UART and data written to the UART will seamlessly be passed to the TCP/IP socket. For information about the latest capabilities of the firmware, please refer to the *WF121 API reference documentation* accompanying it.

The module can also be controlled by a script running on the module. This is especially useful for simple applications as it eliminates the need for a host controller and can drastically cut development time. In combination with a host it can also be used automate certain features such as the serial to TCP/IP functionality described above.

Native application development is also possible as the stack will not require all of the available flash or memory. Please see the material accompanying the firmware release about more details of this option.

9 Host interfaces

9.1 **UART**

The module can be controlled over the UART interface. In order for the communication to be reliable, hardware flow control signals (RTS and CTS) must be present between the host and the module. When using high UART transfer speeds (between 1 and 20Mbps) an external crystal is required for sufficient clock accuracy.

9.2 USB

When using the USB host interface, the module will appear as a USB CDC/ACM device enumerating as virtual COM port. The same protocol can be used as with the UART interface.

9.3 SPI

Please refer to the Bluegiga WF121 API reference documentation supplied with the firmware regarding using SPI as the Host interface.

10 Electrical characteristics

10.1 Absolute maximum ratings

Rating	Min	Max	Unit
Storage Temperature	-40	85	°C
VDD_PA	-0.3	6	V
VDD_3.3V	-0.3	3.6	
5V tolerant GPIO Voltages	-0.3	5.5	V
Other Terminal Voltages	VSS-0.3	VDD_3.3V+0.3	V
Maximum output current sourced or sunk by any GPIO pad		25	mA
Maximum current on all GPIO pads combined		200	mA

Table 13: Absolute maximum ratings

10.2 Recommended operating conditions

Rating	Min	Max	Unit
Operating Temperature Range *	-40	85	°C
VDD_3.3V	2.3	3.6	V
VDD_PA	2.7	4.8	V

Table 14: Recommended operating conditions

*Note: The module will heat up depending on use, at high constant transmit duty cycles (high throughput, low bitrate for more than a few seconds) the maximum operating temperature may need to be derated down to 60°C.

10.3 Input/output terminal characteristics

10.4 Digital

Digital terminals	Min	Тур	Max	Unit
Input voltage levels				
V _{IL} input logic level low 1.7V ≤ VDD ≤ 3.6V	VSS-0.3V	-	0.15VDD	V
V _{IH} input logic level high 1.7V ≤ VDD ≤ 3.6V	0.8VDD	-	VDD+0.3V	V
Output voltage levels				
V _{OL} output logic level low, Vdd = 3.6 V, IoI = 7 mA	-	-	0.4	V
V _{OH} output logic level high Vdd = 3.6 V, loh = -12 mA	2.4	-	VDD	V

Table 15: Digital terminal electrical characteristics

	Min	Тур	max	
Frequency	32.748	32.768	32.788	kHz
Deviation @25°C	-20		+20	ppm
Deviation over temperature	-150		+150	ppm
Duty cycle	30	50	70	%
Rise time			50	ns
Input high level	0.625Vdd		Vdd+0.3	V
Input low level	-0.3		0.25Vdd	V

Table 16: External sleep clock specifications

10.5 Reset

Power-on Reset	Min	Тур	Max	Unit
Power on reset threshold	1.75	-	2.1	V
VDD rise rate to ensure reset	0.05	-	115	V/ms

Table 17: Power on reset characteristics

10.6 Power consumption (preliminary)

Operation Mode	Current	Unit	Operation Mode	
Absolute maximum (+17dBm, CCK)	400	mA	Peak total current (+17dBm, CCK)	
Continuous transmit (+17dBm, CCK)	330	mA	Continuous transmit (+17dBm, CCK)	
Continuous receive (OFDM)	120	mA	Continuous receive (OFDM)	
Sleep	60	μA	Deep sleep (WiFi powered down)	
NOTE: values estimated, measurements to be added later				

Table 18: Power consumption (TBD)

11 RF Characteristics

	min	max	
Channel	1	13	Note: channel 14 (Japan only) can be set but proper operation is not guaranteed and its use should be avoided.
Frequency	2412	2472	MHz

Table 19: Supported frequencies

Standard	Supported bit rates		
802.11b	1, 2, 5.5, 11Mbps		
802.11g	6, 9, 12, 18, 24, 36, 48, 54Mbps		
802.11n, HT, 20MHz, 800ns	6.5, 13, 19.5, 26, 39, 52, 58.5, 65Mbps		
802.11n, HT, 20MHz, 400ns	7.2, 14.4, 21.7, 28.9, 43.3, 57.8, 65, 72.2Mbps		

Table 20: Supported modulations

802.11b	Тур	802.11g	Тур	802.11n short GI	Тур	802.11n long GI	Тур
1 Mbps	-97 dBm	6 Mbps	-92 dBm	6.5 Mbps	-91 dBm	7.2 Mbps	-92 dBm
2 Mbps	-95 dBm	9 Mbps	-91 dBm	13 Mbps	-87 dBm	14.4 Mbps	-90 dBm
5.5 Mbps	-93 dBm	12 Mbps	-89 dBm	19.5 Mbps	-85 dBm	21.7 Mbps	-87 dBm
11 Mbps	-89 dBm	18 Mbps	-87 dBm	26 Mbps	-82 dBm	28.9 Mbps	-84 dBm
		24 Mbps	-84 dBm	39 Mbps	-78 dBm	43.3 Mbps	-80 dBm
		36 Mbps	-80 dBm	52 Mbps	-74 dBm	57.8 Mbps	-75 dBm
		48 Mbps	-75 dBm	58.5 Mbps	-71 dBm	65 Mbps	-72 dBm
		54 Mbps	-73 dBm	65 Mbps	-68 dBm	72.2 Mbps	-69 dBm

Table 21: Typical receiver sensitivity

Modulation type	Min	Тур	Max	
802.11b	+16	+17	+17.6	dBm
802.11g	+14	+15	+15.6	dBm
802.11n	+14	+15	+15.6	dBm

Table 22: Transmitter output power at maximum setting

Modulation type	Min	Тур	Max	
TX loss	-2.5	-3	-3.5	dB
RX gain (using internal LNA)	8	10	12	dB
Internal LNA noise figure		2.0	2.5	dB

Table 23: BT antenna sharing interface properties

	Тур	Max	802.11 limit (total error)	
Variation between individual units	+/-5	+/-10	+/-25	ppm
Variation with temperature	+/-3	+/-10	+/-25	ppm

Table 24: Carrier frequency accuracy

12 Physical dimensions




Figure 4: Physical dimensions




Figure 5: WF121-A recommended PCB land pattern

13 Layout guidelines

13.1 WF121-E

RF output can be taken directly from the U.FL connector of the module, and no antenna clearances need to be made for the module.

13.2 WF121-N

The RF output is taken from the ANT pin at the end of the device. In other variants this pin is not connected. The antenna trace should be properly impedance controlled and kept short.

13.3 WF121-A




Figure 6: Example layouts, board corner placement on left, board edge on right

The impedance matching of the antenna is designed for a layout similar to the module evaluation board. For an optimal performance of the antenna the layout should strictly follow the layout example shown in the above figures and the thickness of FR4 should be between 1 and 2 mm, preferably 1.6mm.

Any dielectric material close to the antenna will change the resonant frequency and it is recommended not to place a plastic case or any other dielectric closer than 5 mm from the antenna.

ANY metal in close proximity of the antenna will prevent the antenna from radiating freely. It is recommended not to place any metal or other conductive objects closer than 20 mm to the antenna except in the directions of the ground planes of the module itself.

For optimal performance, place the antenna end of the module outside any metal surfaces and objects in the application, preferably on the device corner. The larger the angle in which no metallic object obstructs the antenna radiation, the better the antenna will work.

The ANT pad on the antenna end of the WF121-A can be connected to the ground or left unsoldered.

13.4 Thermal considerations

The WF121 module may at continuous full power transmit consume up to 1.3 W of DC power, most of which is drawn by the power amplifier. Most of this will be dissipated as heat. In any application where high ambient temperatures and constant transmissions for more than a few seconds can occur, it is important that a sufficient cooling surface is provided to dissipate the heat.

The thermal pad in the bottom of the module must be connected to the application board ground planes by soldering. The application board should provide a number of vias under and around the pad to conduct the produced heat to the board ground planes, and preferably to a copper surface on the other side of the board in order to dissipate the heat into air.

The module internal thermal resistance should in most cases be negligible compared to the thermal resistance from the module into air, and common equations for surface area required for cooling can be used to estimate the temperature rise of the module. Only copper planes on the circuit board surfaces with a solid thermal connection to the module ground pad will dissipate heat. For an application with high transmit duty cycles (low bit rate, high throughput, long bursts or constant streaming) the maximum allowed ambient temperature should be reduced due to inherent heating of the module, especially with small fully plastic enclosed applications where heat transfer to ambient air is low due to low thermal conductivity of plastic.

The module measured on the evaluation board exhibits a temperature rise of about 25°C above ambient temperature when continuously transmitting IEEE 802.11b at full power with minimal off-times and no collision detection (a worst case scenario regarding power dissipation). An insufficiently cooled module will rapidly heat beyond operating range in ambient room temperature.

13.5 EMC considerations

Following recommendations helps to avoid EMC problems arising in the design. Note that each design is unique and the following list do not consider all basic design rules such as avoiding capacitive coupling between signal lines. Following list is aimed to avoid EMC problems caused by RF part of the module.

- Do not remove copper from the PCB more than needed. For proper operation the antenna requires a
 solid ground plane with as much surface area as possible. Use ground filling as much as possible.
 Connect all grounds together with multiple vias. Do not leave small floating unconnected copper areas
 or areas connected by just one via, these will act as additional antennas and raise the risk of
 unwanted radiations.
- Do not place a ground plane underneath the antenna. The grounding areas under the module should be designed as shown in Figure 4.
- When using overlapping ground areas use conductive vias separated max. 3 mm apart at the edge of
 the ground areas. This prevents RF from penetrating inside the PCB. Use ground vias extensively all
 over the PCB. All the traces in (and on) the PCB are potential antennas. Especially board edges
 should have grounds connected together at short intervals to avoid resonances.
- Avoid current loops. Keep the traces with sensitive, high current or fast signals short, and mind the
 return current path, having a short signal path is not much use if the associated ground path between
 the ends of the signal trace is long. Remember, ground is also a signal trace. The ground will conduct
 the same current as the signal path and at the same frequency, power and sensitivity.
- Split a ground plane ONLY if you know exactly what you are doing. Splitting the plane may cause
 more harm than good if applied incorrectly. The ground plane acts as a part of the antenna system.
 Insufficient ground planes or large separate sensitive signal ground planes will easily cause the
 coupled transmitted pulses to be AM-demodulated by semiconductor junctions around the board,
 degrading system performance.




Figure 7: Use of stitching vias to avoid emissions from the edges of the PCB

14 Soldering recommendations

WF121 is compatible with industrial standard reflow profile for Pb-free solders. The reflow profile used is dependent on the thermal mass of the entire populated PCB, heat transfer efficiency of the oven and particular type of solder paste used. Consult the datasheet of particular solder paste for profile configurations.

Bluegiga Technologies will give following recommendations for soldering the module to ensure reliable solder joint and operation of the module after soldering. Since the profile used is process and layout dependent, the optimum profile should be studied case by case. Thus following recommendation should be taken as a starting point guide.

- Refer to technical documentations of particular solder paste for profile configurations
- · Avoid using more than one flow.
- Reliability of the solder joint and self-alignment of the component are dependent on the solder volume. Minimum of 150μm stencil thickness is recommended.
- Aperture size of the stencil should be 1:1 with the pad size.
- A low residue, "no clean" solder paste should be used due to low mounted height of the component.
- If the vias used on the application board have a diameter larger than 0.3mm, it is recommended to mask the via holes at the module side to prevent solder wicking through the via holes. Solders have a habit of filling holes and leaving voids in the thermal pad solder junction, as well as forming solder balls on the other side of the application board which can in some cases be problematic.

15 Certifications

WF121 is compliant to the following specifications:

15.1 CE

TBD

15.2 FCC

TBD

15.3 IC

TBD

15.4 TELEC

TBD

16 Qualified Antenna Types for WF111-E

This device has been designed to operate with the antennas listed below, and having a maximum gain of 2.14 dB. Antennas not included in this list or having a gain greater than 2.14 dB are strictly prohibited for use with this device. The required antenna impedance is 50 ohms.

Qualified Antenna Types for WT121-E			
Antenna Type	Maximum Gain		
Dipole	2.14 dBi		

Table 25: Qualified Antenna Types for WF111-E

Any antenna that is of the same type and of equal or less directional gain as listed in table 29 can be used without a need for retesting. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that permitted for successful communication. Using an antenna of a different type or gain more than 2.14 dBi will require additional testing for FCC, CE and IC. Please, contact support@bluegiga.com for more information

17 Contact information

Sales: sales@bluegiga.com

Technical support: support@blueqiga.com

http://techforum.bluegiga.com

Orders: orders@bluegiga.com

www.bluegiga.com

www.bluegiga.hk

Head Office / Finland:

Phone: +358-9-4355 060 Fax: +358-9-4355 0660

Sinikalliontie 5A 02630 ESPOO FINLAND

Postal address / Finland:

P.O. BOX 120 02631 ESPOO FINLAND

Sales Office / USA:

Phone: +1 770 291 2181 Fax: +1 770 291 2183 Bluegiga Technologies, Inc.

3235 Satellite Boulevard, Building 400, Suite 300

Duluth, GA, 30096, USA

Sales Office / Hong-Kong:

Phone: +852 3182 7321 Fax: +852 3972 5777

Bluegiga Technologies, Inc.

19/F Silver Fortune Plaza, 1 Wellington Street,

Central Hong Kong